

TIP: If front and rear rails are not even on the left-most part of the shelf, gently tap left end of Power Zone® unit on the floor to even them.

TIP: Begin placing the pusher fixture(s) at the bottom-most left side of the plan-o-gram area. If installing on multiple shelves on the same fixture, work bottom to top and work left to right.

TIP: During installation, once pusher fixture is placed on shelf, test tallest product for easy removal relative to above shelf. If product is too close to shelf above, reposition as needed.

- 2 Notice that the rear rail has non-skid material located underneath, to help unit stay in place on shelf.
- 3 Secure Power Zone® to shelf by inserting fasteners through holes in front rail and shelf. (3 per unit included). To unfasten from shelf, simply lift up assembled unit and fasteners will disengage from shelf.
- 4 The End Divider has two adhesive pads. Remove liner and adhere to left edge of Power Zone® front and rear rails.

(5) Starting with first row on the left end of the Power Zone® System, slide pusher track/divider to match width of product. Load first row of product. Repeat this step until you reach right edge of Power Zone®.

TIP: In rare instances, odd-shaped products do not self-face easily. In this case, firmly place thumb on spring within the track/ divider and push spring forward toward front of track. Spring can be removed through the small opening at front of the track.

- (6) Place next Power Zone® System on top of store shelf. NOTE: Left End Divider not needed when connecting two units together. Line up Power Zone® front and rear rails with previously installed Power Zone® System. Align holes in front rail with shelf holes. Secure with fasteners.
- The last pusher track/divider will be used as the right end divider.
- (8) To add or remove track/dividers, slide track/divider into or out of the front and rear rails from the right end of the system.

20190311

