



NOTE: 2 lengths of Chain per ceiling hook are included along with S-Hooks for adapting to ceiling height.

Place the Jack Chain onto "Warehouse Ceiling Hook for Solid Beam". Keep the Jack Chain off to the side and away from the neck of the Ceiling Hook. Lower neck of Ceiling Hook into the top of the Installation Pole.

- Lift Installation Pole up to solid beam in store. Continue to lift up until Ceiling Hook is surrounding the solid beam.
- Twist Installation Pole about a quarter turn. Lower Installation Pole until Ceiling Hook can rest on beam.
- Remove Installation Pole from Ceiling Hook and let Jack Chain settle into the neck of the Ceiling Hook.



