



① Locate the opening among the Panels.



② Slide the back of the Locking Panel up under the Left and Right Panels. The Left Side of the Locking Panel will clamp around part of the Left Panel and the Right Side of the Locking Panel will clamp around part of the Right Panel. **NOTE:** You may need to slide Right Panel into Locking Panel for an accurate fit.



③ Lift Locking Panel front up to close around the Left and Right Panels. Lock with the key.



④ Remove key. Installation is complete.