




① Turn key clockwise to open box.



② Slide out **PART A** (with key).



③ Angle **PART A** to remove from **PART B**.



④ Insert self-tapping screws into **SMALL HOLES** located in the bottom of **PART B**. Use a short handle screw driver to tighten self-tapping screw to countertop.



⑤ Tighten self-tapping screws into countertop.



⑥ Insert graphic into side opening in front panel of **PART A**.



⑦ Angle **PART A** to insert into **PART B**.



⑧ Slide **PART A** back into **PART B**.



⑨ Turn key counter-clockwise to lock Coin Box. Remove keys and keep in a safe place.