

- ① Insert key into Hook Lock. Turn the key clockwise (to the right), to release barrel and then remove the key.
- ② Select a hook to protect. Slide the Hook Lock onto to the end of the hook.
- ③ Push the barrel back into the Hook Lock until it snaps into place to lock.
NOTE: DO NOT MISPLACE OR LOSE KEYS.
- ④ Hook Lock is installed.

REMOVE HOOK LOCK FROM HOOK

Insert key into Hook Lock. Turn the key clockwise (to the right), to release barrel and then remove the key. Slide the Hook Lock off of the hook.

