



### Care of your Motion Mat®

Motion Mat® is designed to be a disposable solution for your gravity feed needs. You can extend the life of your Motion Mat® by keeping it clean. Periodically as required, wipe the Motion Mat® with a soft cloth and warm water and, if necessary, use a mild soap. If the Motion Mat® gets too dirty or shows signs of wear, it's time for a replacement Motion Mat®.