





Single Basket:
Recommended **MAXIMUM**
load is 50 lbs




Double Basket:
Recommended **MAXIMUM**
load is 25 lbs per basket




Single Kit



- ① Loosen thumbscrews (A).
- ② Pull out extender arms (B) to fit bunker case.
- ③ Set the extender arm sides (B) onto top edge of bunker case.
- ④ Tighten thumbscrews (A).



Double Kit



- ① Loosen thumbscrews (A).
- ② Pull out extender arms (B) to fit bunker case.
- ③ Set the extender arm sides (B) onto top edge of bunker case.
- ④ If extender arms do not reach top edge of bunker case, loosen thumbscrews (C) on extender tube & pull out extender arms for more extension.
- ⑤ Tighten all thumbscrews (A&C).

